



AtlasX Prime

Frequently Asked Questions

HOW DOES ATLASX PRIME COMPARE TO FUEL CONTROL PEDESTALS?

Gasboy AtlasX PRIME merges the latest fueling control technology with trusted Gasboy AtlasX fuel dispensers. Each fueling position has its own integrated user interface for authorizing transactions and collecting driver and vehicle information.

The AtlasX PRIME point-of-use fuel authorization terminal provides a faster, safer, and more intuitive fueling experience at commercial fleet fueling sites.

Separate fuel control pedestals are not needed at AtlasX PRIME locations, simplifying installation and increasing site uptime.

WHAT METHODS OF ACCESS CONTROL ARE AVAILABLE?

AtlasX PRIME has several options for access control:

- Keypad or Mifare (standard feature)
- Mag stripe cards (standard feature)
- HID, Universal, or Indala (optional)
- Gasboy FuelPoint Vehicle ID (optional)

WHAT CONNECTIVITY OPTIONS ARE AVAILABLE FOR ATLASX PRIME?

AtlasX PRIME dispenser can be wired with CAT 5 cable from the customer network to each fueling dispensers. Alternatively, point to point wireless devices can be field installed to link the dispensers to the customer network.

IS ATLASX PRIME COMPATIBLE EKOS?

Yes, AtlasX PRIME is compatible EKOS.

WHAT MODELS ARE AVAILABLE WITH ATLASX PRIME?

AtlasX Prime is available as a factory installed option for the following AtlasX models

Series	Description
9800	AtlasX Electronic High Flow Pumps and Dispensers
9850	AtlasX Electronic Ultra High Flow 50 GPM Pumps and Dispensers
9860	AtlasX DEF Warm and Cold Weather Dispensers

WHAT IS THE WARRANTY WITH THE ATLASX PRIME?

AtlasX PRIME is covered under the AtlasX dispenser warranty and are warranted against defects in material and workmanship for 12 months from the date of installation or 24 months from the date of original invoice, whichever occurs first. The warranty coverage includes parts and labor.

WHERE CAN I FIND ADDITIONAL INFORMATION ON ATLAS PRIME?

Additional documents can be found on at:

<https://www.gasboy.com/us/products/commercial-fleet-dispensers/atlas-prime>

- P-2597 Product Information Sheet
- P-7080 AtlasX Brochure

Technical documentation can be found at:

<https://www.gasboy.com/us/content/technicaldocumentation>

- MDE-5803A - AtlasX Prime Installation and Startup Manual
- MDE-5414 PRIME Set-Up Manual
- MDE5415 User Manual
- PT-1949 AtlasX Pump and Dispenser Illustrated Parts Manual